Python Environment Setup on Windows

1. Install Package Manager

Chocolate

It is the package manager for windows. Following the install step on the website to install it.

```
C:\Windows\system32>choco
Chocolatey v0.10.13
Please run 'choco -?' or 'choco <command> -?' for help menu.
C:\Windows\system32>
```

2. Install More Handy Terminal

ConEmu

Using choco to install it.

> choco install conemu

```
:\Windows\system32>choco install conemu
Installing the following packages:
By installing you accept licenses for the packages.
Progress: Downloading ConEmu 19.3.10.0... 100%
onemu package files install completed. Performing other installation steps.
he package ConEmu wants to run 'chocolateyInstall.ps1'.
lote: If you don't run this script, the installation will fail.
lote: To confirm automatically next time, use '-y' or consider: hoco feature enable -n allowGlobalConfirmation
Do you want to run the script?([Y]es/[N]o/[P]rint): y
Downloading ConEmu 64 bit
 from 'https://github.com/Maximus5/ConEmu/releases/download/v19.03.10/ConEmuSe
Progress: 100% - Completed download of C:\Users\iec070624\AppData\Local\Temp\chc
colatey\ConEmu\19.3.10.0\ConEmuSetup.190310.exe (6.65 MB).
Download of ConEmuSetup.190310.exe (6.65 MB) completed.
Hashes match.
Installing ConEmu...
ConEmu has been installed.
The install of conemu was successful.
Software installed as 'exe', install location is likely default.
Chocolatey installed 1/1 packages.
See the log for details (C:\ProgramData\chocolatey\logs\chocolatey.log).
 :\Windows\system32>
```

3. Install Git Bash


· Git for Window

Download and Install it.

4. Open ConEmu

Opening ConEmu and choose git bash, then you can use Unix-commands.

git bash



5. Install Python3

1. Install Miniconda3

```
$ choco install miniconda3 --params="'/AddToPath:1'"
```

```
$ choco install miniconda3 --params="'/AddToPath:1'"
Chocolatey v0.10.13
Installing the following packages:
miniconda3
By installing you accept licenses for the packages.
miniconda3 v4.5.12 already installed.
Use --force to reinstall, specify a version to install, or try upgrade.
Chocolatey installed 0/1 packages.
See the log for details (C:\ProgramData\chocolatey\logs\chocolatey.log).
Warnings:
    - miniconda3 - miniconda3 v4.5.12 already installed.
Use --force to reinstall, specify a version to install, or try upgrade.
```

then you can use conda and python

2. If you want to use python3.6

```
$ conda install python=3.6
```

or create a new environment (Recommend)

```
$ conda create --name py36 python=3.6
```

```
$ conda create --name py36 python=3.6
Solving environment: ...working... done
## Package Plan ##
 environment location: C:\tools\miniconda3\envs\py36
 added / updated specs:
   - python=3.6
The following packages will be downloaded:
   package
                                     build
   setuptools-40.8.0
                                    py36_0
                                                 664 KB
                              py36h7fe50ca_0
                                                 13 KB
   wincertstore-0.2
   python-3.6.8
                                 h9f7ef89_7
                                                 20.3 MB
   wheel-0.33.1
                                  py36_0
                                                 57 KB
   certifi-2019.3.9
                                    py36_0
                                                 156 KB
   pip-19.0.3
                                                 1.9 MB
                                    py36_0
   sqlite-3.27.2
                                 he774522 0
                                                 941 KB
                                                24.0 MB
                                    Total:
The following NEW packages will be INSTALLED:
               2019.3.9-py36_0
   certifi:
                19.0.3-py36_0
   python:
               3.6.8-h9f7ef89_7
   setuptools: 40.8.0-py36_0
sqlite: 3.27.2-he774522_0
                 14.1-h0510ff6 4
   vs2015_runtime: 14.15.26706-h3a45250_0
   wheel:
                0.33.1-py36_0
   wincertstore: 0.2-py36h7fe50ca_0
Proceed ([y]/n)? y
==> WARNING: A newer version of conda exists. <==
  current version: 4.5.12
  latest version: 4.6.8
Please update conda by running
    $ conda update -n base -c defaults conda
                       664 KB
                                     | ######## | 100%
setuptools-40.8.0
                       13 KB
wincertstore-0.2
                                       ######## | 100%
                        20.3 MB
                                       ######## | 100%
python-3.6.8
                        57 KB
                                       ######## | 100%
wheel-0.33.1
certifi-2019.3.9
                       | 156 KB
                                      ######## | 100%
                                      #########
                                                     100%
pip-19.0.3
                        1.9 MB
                                     | ######## | 100%
                       941 KB
sqlite-3.27.2
Downloading and Extracting Packages
Preparing transaction: ...working... done
Verifying transaction: ...working... done
Executing transaction: ...working... done
# To activate this environment, use:
# > activate py36
# To deactivate an active environment, use:
# > deactivate
# * for power-users using bash, you must source
```

3. Activate the environment of py36

```
$ source activate py36
(py36)
```

```
$ python -i
Python 3.6.8 |Anaconda, Inc.| (default, Feb 21 2019, 18:30:04) [MSC v.1916 64 bit (AMD64)] on win32
Type "help", "copyright", "credits" or "license" for more information.
>>> exit()
(py36)
```

Note:

Because git bash use MinTTY that doesn't support interactive operation, If you want to use python interactive shell, you can follow the method as follows

```
$ python -i
```

```
$ python -i
Python 3.7.1 (default, Dec 10 2018, 22:54:23) [MSC v.1915 64 bit (AMD64)] :: Anaconda, Inc. on win32
Type "help", "copyright", "credits" or "license" for more information.
>>> exit()
```